


Music




Please read me before using

Safety information

- * please read and keep this manual, and pay attention to the below warnings
- * please put this speaker in a stable place, to avoid any damage caused by accident dropping
- * please keep this speaker away from any liquid or fire.
- * Please do not leave this speaker in high temperature, or high moist environment for long time.
- * Please turn off the speaker when do not use it.

1: Sketch map



Instruction

1. Press  for ON/OFF

2. AUX Line in

This speaker can connect to all kinds of audio devices (such as mobile phone, ipad, MP3 player, cassette player, CD player, radio, etc) insert the 3.5MM AUX plug into the earphone jack of the audio device (the computer earphone jack is green)

3. play

after connection of the audio, it can play the audio file in the computer or mobile phone. volume up and down need to be controlled on the audio device (computer, laptop, mobile phone)

4. charging

insert one end of the cable to the charging slot of speaker, the USB plug to the computer or the mobile charger (DC 5v, 500MA)

Backside indicator light on red indicates It is charging
Light off indicates charging finished.

Specification

Battery : 3.7V 300MAH

Power input : DC5V 500MA

Power output : 3W

Rated impedance: 4 0HM

frepuncy rseponse : 50-1800HZ

SNR : 80DB

THD+N: 0.3%

Driver size : 1.4寸

Product size : 47*47*34MM